



BKHD-1090NP-20-6LAN Motherboard

VER 1.1

Copyright Notice

©2024 Beikong Industrial Control. All rights reserved.

All trademarks, service marks, company names, and logos referenced in this manual are the property of their respective owners. Any use of these trademarks, service marks, company names, and logos without express written permission from Beikong Industrial Control or the respective trademark owners is strictly prohibited.

Responsibility Statement

This user manual and its contents, including text, images, charts, and other materials, are protected by copyright law and are the property of Beikong Industrial Control. Please be advised that without the written permission of Beikong Industrial Control, the manual may not be copied, distributed, displayed, modified, created as a derivative work, transmitted, or publicly performed or displayed in any way or form.

Beikong Industrial Control reserves the right to modify the product specifications, features, designs, or any related information mentioned in this user manual at any time without prior notice. Please be advised that any such modifications will take effect without further notice.

Any reproduction, modification, reprinting, transmission, or publication of the contents of this manual in any form without prior written permission from Beikong Industrial Control is strictly prohibited. Any violation of this statement may result in legal action and damages.

Safety Guide

To ensure optimal use of Beikong products, please review the user manual in its entirety. Before reviewing product-specific information, we kindly request that you carefully read the safety instructions.

Product Version Identification


The product version number can be found on the motherboard, where X.X represents a number. For example, if the version is indicated as [VER1.0], it signifies that the current version of the motherboard is 1.0. The BIOS interface homepage provides information such as [XXXXNP-XXXX], which denotes the BIOS version number utilized by the current product. When updating the motherboard's BIOS, driver, or referencing other technical documents, please refer to the product version label for the most up-to-date information.

Catalog

Copyright Notice	1
Responsibility Statement	1
Safety Guide	1
Product Version Identification	1
Product Images	3
Product Profile	4
Motherboard Specifications	5
Motherboard Installation	6
Memory Installation	7
Motherboard Interface & Pin Description	8
Jumper Setting	10
Restore on AC/Power Loss (AUTO_ON)	11
ME Flashing Selection Jumper (J_ME)	11
CMOS Clear Selection Jumper (CLR_CMOS)	11
Motherboard Pin Definition	12
SATA Data	12
SATA PWR	12
Serial Port (COM)	13
Front Panel Connectors (F_PANEL)	14
USB Connectors Pins (F_USB1/2)	14
VGA Expansion Pins (VGA_H)	15
HDMI Expansion Pins (J_HDMI)	15
Keyboard And Mouse Interface (JPS2)	16
Cooling Fan Power Socket (CPU_FAN/SYS_FAN)	16
ATX Power Connector (DC power supply)	17
SIM card slot (SIMB)	17
BIOS User Guide	18
BIOS Description	18
BIOS Settings	19
Common fault analysis and solutions	20
Useful Links	21

Product Images

Please be advised that products manufactured in different batches may exhibit slight variations in appearance. To ensure the most accurate representation, please refer to the actual received goods.



Product Profile

The 1090NP-20-6LAN is a high-performance industrial motherboard built on the Intel Celeron J-series and Pentium Silver processor platform. It integrates 6x 2.5GbE Ethernet ports, dual-channel DDR4 memory support, rich expansion interfaces, and wide-temperature industrial reliability. Designed for applications requiring high network density, large bandwidth throughput, and stable long-term operation, it is ideal for advanced software routers, network security appliances, industrial gateways, and edge computing systems.

Main features:

High-Speed Networking Performance

Equipped with six Intel I226V 2.5GbE controllers, delivering up to 15 Gbps aggregate bandwidth. Compared to traditional Gigabit networking, it offers 2.5x higher bandwidth, enabling high-throughput performance for multi-WAN routers, firewalls, VPN gateways, and network monitoring systems—easily handling complex packet processing and traffic policies.

Proven Computing Platform

Powered by Intel Celeron J-series or Pentium Silver processors, the platform delivers reliable, field-proven performance with excellent energy efficiency. Dual-channel DDR4 SO-DIMM slots ensure smooth multitasking and stable operation under high network workloads.

Industrial-Grade Reliability

Designed for wide-temperature operation, ensuring stable performance in harsh environments such as outdoor deployments and high-temperature industrial sites. Flexible power options support DC 12V input or standard ATX 12V 4-pin, allowing easy integration into various system architectures.

Flexible Expansion Interfaces

Includes an mPCIe slot for Wi-Fi or LTE modules, along with an onboard SIM card slot for cellular connectivity. Additional headers such as COM, PS/2, and multiple USB 2.0 headers provide flexible expansion for serial devices, peripherals, and front-panel connectivity.

Storage and Thermal Design

Supports one SATA interface and one mSATA slot, enabling flexible combinations of high-speed SSD and high-capacity storage. Dedicated CPU and system fan headers ensure reliable thermal performance under sustained workloads.

Motherboard Specifications

Processor	Product Collection	Intel Celeron Processor J Series Intel Pentium Silver Processor Series	
	Sockets Supported	FCBGA1090	
Memory specifications	Memory Type	DDR4 SO-DIMM	
	Maximum Capacity	2x 8GB	
	Maximum Frequency	2400 MHz	
Storage specifications	SATA	1*SATA 6Gb/s	
	mSATA	1*mSATA	
Network features	Ethernet	6*2.5GbE	
	Controller	6*Intel I226V	
Extension interface	mPCIe	1*mPCIe (USB2.0 signal)	
Display functions	Pins	1*VGA/1*HDMI	
	Chip	Intel UHD Graphics	
Backplane I/O	Ethernet	6*RJ45	
	USB	2*USB-A 3.0	
	Console	1*RJ45 COM	
	Button	1*Power button, 1*Reset button	
	Power supply	1*Jack DC 5.5/2.5mm	
Onboard I/O	SATA	1*SATA Data connector, 1*SATA Power socket	
	Display	1*J_VGA/1*J_HDMI	
	SIM	1*SIM Card slots	
	Fan	1*CPU_FAN, 1*SYS_FAN	
	Pins		1*F_PANEL
			1*J_COM (RS232)
			2*F_USB 2.0 (can expand 4x USB2.0 ports)
		1*J_P/S 2	
Power supply mode	Power	1*ATX 12V 4-pin Connector or 1*Jack DC 12V	
Motherboard size	Specification	180*200 (mm)	
Work Environment	Temperature	-20~55°C (Operating); -20°C~75°C (Storage)	
	Humidity	0%~95% (Relative humidity, no condensation)	


Motherboard Installation

Safety Note

- Please do not remove the serial number and agent warranty sticker from the motherboard prior to installation. Doing so may affect the product's warranty recognition standard.
- Prior to installing or removing the motherboard or other hardware devices, please ensure that the power is turned off and the power cord is unplugged from the socket.
- When installing additional hardware devices on the motherboard interfaces, please ensure that the connectors and sockets are securely fastened.
- When handling the motherboard, please avoid contact with the metal wiring components to prevent the risk of short circuits.
- It is recommended that an anti-static wrist strap be worn when handling the motherboard, central processing unit (CPU), or memory. In the absence of an anti-static wrist strap, it is advisable to ensure that your hands are dry and to touch a metal object first in order to eliminate static electricity.
- Before installing the motherboard, we kindly request that place it on an antistatic mat or in an antistatic bag.
- Make sure the power adapter is turned off before unplugging the motherboard power connector.
- Before turning on the power, make sure the voltage of the adapter is within the standard voltage range.
- Before turning on the power, make sure all hardware device cables and power cords are properly connected.
- Do not allow the fixing screws to collide with the circuits or parts on the motherboard to avoid damage or malfunction of the motherboard.
- Make sure there are no loose screws or metal parts on the motherboard or inside the computer case before using the unit.
- Please secure the computer host in a stable location before starting the device.
- To prevent system failure, do not place the unit in an environment where the temperature is excessive.
- Turning on the power before installation is complete may damage the motherboard, other equipment, or yourself.
- If you are unfamiliar with how to perform the installation, or if you have any technical problems using this product, please contact a professional technician.

Memory Installation

The motherboard provides DDR4 SODIMM memory slot.



Before installing memory:

1. Please confirm that the memory you purchased is compatible with the specifications supported by this motherboard.
2. Before installing or removing the memory, please make sure that the power of the computer is turned off to avoid damage.
3. The memory design has a foolproof mark. If you insert the memory in the wrong direction, the memory cannot be installed. Please change the direction.


When installing memory:

1. Before installing or removing memory, please turn off the power and unplug the power cord.
2. Carefully hold the two ends of the Memory Stick and do not touch the metal contacts on the Memory Stick.
3. Align the metal contacts of the memory with the memory slot, making sure that the concave hole is aligned with the convex point of the upper slot.
4. Insert the memory into the slot at an angle of 30 degrees, then press the Memory Stick down until you hear a "click," indicating that the memory has been successfully installed and is ready to use. (Note: Do not press the Memory Stick too hard to avoid damaging the memory).
5. To remove the Memory Stick, push out the tabs at both ends of the memory slot simultaneously, and then remove the Memory Stick.

To remove the memory:


Use two fingers to push the latches at either end of the slot outward, the memory will pop up, then remove the memory.

Motherboard Interface & Pin Description



Item	Describe
KM	Expandable for connecting keyboard and mouse
COM 2	Can be used to expand COM ports
JHDMI	Can be used to expand HDMI ports
VGA_H	Can be used to expand VGA ports
AUTO_PWMON	Restore on AC function jumper
SATA_PWR	SATA HDD/SSD Power Socket
SATA	SATA HDD/SSD Data Connectors
MSATA	Mini SATA SSD slot

SYS_FAN	For Chassis fan power supply
F_PANEL	Motherboard function pin, used to connect chassis button
CLR_CMOS	CMOS Clear Selection jumper
J_ME	ME flashing selection jumper
F_USB 1/2	Can be used to expand USB2.0 ports
MPCIE	Mini PCIe slot
SODIMM 1/2	DDR4 SO-DIMM memory slot (RAM)
CPU_FAN	For CPU fan power supply
DC_IN	Jack DC 5.5/2.5mm Power connector, 12V
DC_ATX	ATX 12V Connector (4-Pin)



Item	Describe
RST_BTN	Reset Button
PWR_BTN	Power Button to turn the device ON or OFF
COM	RJ45 port for COM RS232 standard
PWR_LED	LED Indicator (Power: Green; Hard disk: Red)
RJ45 Connectors	RJ45 Ethernet port for LAN/WAN
	Link LED: Green and solid, indicating the network is connected Active LED: Orange flashing, indicating data transmission

Jumper Setting


Before installing the hardware device, you can set the corresponding jumpers according to your needs based on the following table.

To identify the first pin of a jumper or connector


Look at the marking next to the jumper or connector. The triangle symbol "▲" or "1" or a bold line indicates the first pin; check the pad on the back of the motherboard. The square pad is the first pin. When connecting the connector to the device, be careful to distinguish the first pin. Mixing the pins will damage the motherboard.

2-pin headers: Insert a jumper cap into both pins turns them off (short).


3-pin headers: Insert a jumper cap into pins 1-2 or pins 2-3 to off (short) them.




Restore on AC/Power Loss (AUTO_ON)

Image	Status	Setting
	1-2	Automatic power on (Default)
	2-3	Normal

ME Flashing Selection Jumper (J_ME)

Image	Status	Setting
	1-2	Disable
	2-3	Enable (Default)

CMOS Clear Selection Jumper (CLR_CMOS)


Image	Status	Setting
	1-2	Normal (Default)
	2-3	CMOS Data Clearance

Before clearing the CMOS, please turn off the device and disconnect the power to avoid damaging the motherboard.

Motherboard Pin Definition


SATA Data

The motherboard provides 7-pin SATA data socket

Image	PIN	Definition	PIN	Definition
	1	GND	2	SATA_TXP
	3	SATA_TXN	4	GND
	5	SATA_RXN	6	SATA_RXP
	7	GND		-

SATA PWR


The motherboard provides 4-pin SATA power socket

Image	PIN	Definition
	1	+12V
	2	GND
	3	GND
	4	+5V


Tip: The 1st pin of the SATA_PWR hard disk power supply interface is +12V output, and the 4th pin is +5V output.

Serial Port (COM)

The motherboard provides RJ45 COM port:

Image	PIN	Definition	PIN	Definition
	1	RTS#	2	DTR#
	3	TXD	4	N/A
	5	GND	6	RXD
	7	DSR#	8	CTS#

The motherboard provides COM pins (2*5-pin, 2.54 mm pitch, 10th pin is empty)

Image	PIN	Definition	PIN	Definition
	1	DCD#	2	RXD
	3	TXD	4	DTR#
	5	GND	6	DSR#
	7	RTS#	8	CTS#
	9	RI#		

Front Panel Connectors (F_PANEL)


The motherboard provides F_PANEL pins (2*5-pin, 2.54 mm pitch, 10th pin is empty)

Image	PIN	Definition	PIN	Definition
	1	HDD_LED+	2	PWR_LED+
	3	HDD_LED-	4	PWR_LED-
	5	GND	6	POWER-SW
	7	RESET	8	GND
	9	GND		

USB Connectors Pins (F_USB1/2)


Before connecting the USB expansion board, be sure to turn off the computer and unplug the power cord from the socket to avoid damaging the USB expansion board.

The motherboard provides F_USB pins (2*5-pin, 2.54 mm pitch, 9th pin is empty)

Image	PIN	Definition	PIN	Definition
	1	+5V	2	+5V
	3	USB1_DATA-	4	USB2_DATA-
	5	USB1_DATA+	6	USB2_DATA+
	7	GND	8	GND
			10	GND


VGA Expansion Pins (VGA_H)

The motherboard provides VGA_H pins (1*12-pin, 2.00 mm pitch)

Image	PIN	Definition	PIN	Definition
	1	GND	2	VSync
	3	HSync	4	GND
	5	Red	6	GND
	7	Green	8	GND
	9	Blue	10	GND
	11	DCC_DATA	12	DCC_CLK


HDMI Expansion Pins (J_HDMI)

The motherboard provides JHDMI pins (2*8-pin, 2.00 mm pitch)

Image	PIN	Definition	PIN	Definition
	1	TMDS_TX2P	2	DCC_Clk
	3	TMDS_TX2N	4	DCC_Data
	5	TMDS_TX1P	6	N/A
	7	TMDS_TX1N	8	HPD_HDMI
	9	TMDS_TX0P	10	+5V
	11	TMDS_TX0N	12	GND
	13	TMDS_TXCP	14	GND
	15	TMDS_TXCN	16	GND


Keyboard And Mouse Interface (JPS2)

The motherboard provides Mouse and Keyboard Connectors pins (1*7-pin, 2.00 mm pitch)

Image	PIN	Definition
	1	KB_DATA
	2	KB_CLK
	3	GND
	4	MS_DATA
	5	MS_CLK
	6	GND
	7	+V5S

Cooling Fan Power Socket (CPU_FAN/SYS_FAN)


The motherboard provides Cooling Fan pins (1*4-pin, 2.54mm pitch)

Image	PIN	Definition
	1	Ground
	2	+12V
	3	FAN_TAC
	4	FAN_PWM

ATX Power Connector (DC power supply)

Before plugging the power supply into the power outlet, make sure the power supply is turned off and all devices are properly installed. The power outlet has a foolproof design; ensure the correct orientation before plugging it in.

(**Do not** use it and the panel's DC IN connector to power the motherboard at the same time.)

Image	PIN	Definition
	1	Ground
	2	Ground
	3	+12V
	4	+12V

SIM card slot (SIMB)

The motherboard provides SIM card slot for installing an LTE SIM card.



Note: When inserting the SIM card, make sure the chip is facing downwards (the chip faces the motherboard).

BIOS User Guide

BIOS Description

This motherboard uses AMI BIOS. BIOS stands for (Basic Input Output System). It is a set of programs stored on a ROM (Read Only Memory) chip on the computer's motherboard. It stores the computer's most important basic I/O programs, the power-on self-test program, and the system startup program. It can read and write specific information about system settings from the CMOS. Its primary function is to provide the most basic and immediate hardware settings and control for the computer.

When you turn on your computer, the BIOS is the first program to run. It has the following main functions:

- The Power-On Self-Test (POST) checks whether the computer is functioning properly.
- It initializes and tests some external devices and loads your operating system.
- It provides the lowest-level, most basic control of your computer hardware.
- You manage your computer through the SETUP function in the BIOS.

The BIOS data is stored in a CMOS/RAM chip on the motherboard, maintained by a 3.3V button battery. It contains important system information and the BIOS Setup program for setting system parameters. When the system is operating normally, the BIOS does not need to be modified. However, if the CMOS data is lost due to other reasons, the BIOS must be reset.

Note:

Incorrect BIOS settings can directly damage the computer hardware and even burn out the motherboard. Those unfamiliar with the system are advised to modify the settings with caution. Because the motherboard BIOS is constantly being updated, the BIOS information in this manual is for reference only. We cannot guarantee that the BIOS information in this manual will be consistent with the actual BIOS information on the motherboard.

BIOS Settings

When the motherboard is powered on or the system is restarted, the following prompt will appear on the display screen in the Post interface. Press "DEL" on the keyboard to enter BIOS Setup.



If this message disappears before you respond, you can press <Ctrl> + <Alt> + at the same time to restart the computer, or shut down and then restart the computer, or press the power button on the case to restart the computer.

Keyboard keys	Functional Description
← / →	Move the Left and Right arrows to select the screen.
↑ / ↓	Move the Up and Down arrows to select the item.
+ / -	Increase/Decrease value or Change selection
<Enter>	Select, Confirm this option or Enter the submenu
<ESC>	Return to Main page, or End the setup process from Main page
<F1>	Show related Help instructions
<F2>	Restore previous settings
<F9>	Load the optimized settings (BIOS defaults)
<F10>	Save the changed settings and reboot

Common fault analysis and solutions

We have compiled some frequently asked questions for your reference. Please check <https://bkminipc.com/frequently-asked-questions-and-answers/>

Error	Inspection Method
Unable to start after power on	<p>Make sure the power cord is properly connected.</p> <p>Make sure that the power supply you are using meets the power supply requirements of the motherboard.</p> <p>Try to reinsert the Memory Stick.</p> <p>Try to replace the Memory Stick.</p> <p>Try to clear the CMOS of the main board.</p> <p>Please confirm if there is an external expansion card and if it is normal after removing the external card.</p>
Unable to display after power on	<p>Make sure the monitor is turned on.</p> <p>Make sure the monitor and host power cables are properly connected. Make sure the monitor and host cables are properly connected.</p> <p>Check to see if the monitor is in "Sleep" mode.</p> <p>Try changing the monitor interface or replacing the monitor.</p>
BIOS Setup cannot be saved	<p>Check that the CMOS battery is installed</p> <p>Try to replace the CMOS battery (CR2032)</p> <p>Adjust the time and date in BIOS setup</p>
Unable to find a bootable device	<p>Make sure the drive's power and data cables are properly connected.</p> <p>Make sure the operating system is installed on the drive.</p> <p>Make sure the hard drive is not physically damaged.</p>
Blue screen or freeze when logging on to the system	<p>Check if the Memory Stick and External Card are loose.</p> <p>Try removing the newly installed hardware and uninstalling the newly installed driver or software.</p> <p>Try replacing the memory with a different specification.</p>
Slow entry into the operating system	<p>Check if the CPU cooling fan is running normally.</p> <p>Check if the remaining space of the system partition is insufficient.</p> <p>Use software to check for bad sectors on the hard drive.</p>
System restarts automatically	<p>Confirm that the CPU cooling fan is rotating normally.</p> <p>Confirm that the switch/reset button has not been accidentally touched.</p> <p>Confirm that the Memory Stick and external card are loose.</p> <p>Confirm that the power supply has sufficient load capacity, try to replace the power supply</p> <p>Check if the system is infected with viruses.</p>
Unable to detect USB device	<p>Confirm that the USB device requires separate power.</p> <p>Confirm that the USB interface has poor contact.</p> <p>Confirm that the USB controller is enabled in the BIOS setup.</p>

Useful Links

Submit your suggestions and ideas in the community	https://www.reddit.com/r/bkminipc/	
Watch our new product demos	https://www.youtube.com/@BKHD-PCs	
Corporate News and Cooperation	https://www.linkedin.com/company/beikong/	
Get our latest news on Meta	https://www.facebook.com/people/%E5%80%8D%E6%8E%A7/61558406109357/	